

Continue



























Let us answer your questions relating to returns, where to buy Photive products, along with any other questions or concerns you have about the Photive brand. User Manuals, Guides and Specifications for your Photive PH-M90 Speakers. Database contains 2 Photive PH-M90 Manuals (available for free online viewing or downloading in PDF): Operation & user's manual . Photive PH-M90 Rugged Bluetooth Speaker Manual PACKAGE PH-M90 speaker USB charging cable 5mm audio cable FUNCTIONS LED light indication Power button Volume down/ Previous track Volume up/ Next track Play/Pause/Pair/Answer calls Screw mount AUX-IN USB charging port Subwoofer CHARGING Before using your PH-M90, please charge it using the micro USB charging cable included in the package. Please note: Most USB chargers are compatible with PH-M90. For optimal AC charging, please use a 1.0A USB charger. Plug the small micro USB pin into the charging port on the rear side of the speaker, and the other end of the cable (the standard USB 2.0 plug) into any standard USB port (such as a computer or USB charger). The LED light on the rear side of the speaker will turn red when it is being charged. When it is fully charged, the LED indicator light will turn off. The speaker can be charged while playing music. PAIRING Press and hold to turn your speaker on. The Bluetooth LED indicator will flash blue. Enable your Bluetooth device such as cell phones, tablets or other Bluetooth media and make sure it is in searching mode. Select "Photive PH-M90 speaker" in the list shown in the Bluetooth device. Note If it prompts, please enter password "0000" for a connection. The speaker will automatically reconnect to the last connected Bluetooth enabled audio device. When you need to connect your speaker with another Bluetooth enabled audio device, hold the PAIRING button about 4-5 seconds until the Bluetooth LED indicator flashes quickly. This will put the speaker into pairing mode. LINE-IN If your device is not Bluetooth enabled you can still enjoy your music simply by using the Line-In Audio jack. Connect the speaker with the audio cable that is included in the package to any device with a 3.5mm standard audio jack. Once connected the speaker can be used as a wired speaker. Please note: the changing track buttons, and only work when connected wirelessly via Bluetooth. Volume function will work in Aux-in mode. HANDS-FREE SPEAKERPHONE You can use PH-M90 as a portable speakerphone for incoming calls when connected wirelessly and outgoing calls via Bluetooth. Take your call by pressing the . Press once again when ending the call. Music will resume automatically. To make a call, simply dial your cell phone and talk to the speaker. Once your call is connected, choose PH-M90 in the headset options. OPERATION INSTRUCTION VOLUME ADJUSTMENT At any time while playing music, the volume can be changed with the or button. To raise the volume, press the button. To lower volume, press the button. There will be a tone from the speaker to indicate that the level has reached maximum or minimum volume. CHANGING TRACKS Press the or button about 2-3 seconds to change tracks. Please note: If listing to music via the Aux line in the track controls on the speaker will not function. Control the track from the device playing audio "ie: Smartphone, Tablet." PLAY AND PAUSE Press the on the speaker to play/pause the music. TROUBLESHOOTING No power Ensure the speaker is charged and with enough power for operation. The speaker can be used when it is in charging mode. No sound Ensure the speaker is on. Ensure your Bluetooth device is on. If the volume of the speaker is too low, adjust the volume to an appropriate level. Unable to connect Press the pairing button until the LED indicator flashes quickly. The Bluetooth speaker will go into pairing mode. Select PH-M90 on your Bluetooth enable device. Poor sound quality from the bluetooth device Ensure placing the speaker and Bluetooth device within 33-ft. (10m) sensing distance and with no barriers. Notes Clean the speaker with a soft, lint-free, dry cloth. Never use detergents or abrasive cleaners for cleaning. SPECIFICATION Speaker parameters Output power 8W x 2 Impedance 4Ω Frequency response: 90hz-20khz Sensitive 70db+/-2db S/N 65db Power Input: DC 5V 2600mA X 2 Playing music time: up to 10 hours Charging time: 6 hours Bluetooth parameters Effective distance 33ft (10m) Bluetooth: 2.1 + EDR NOTES Do not expose the built-in battery to excessive heat, including direct sunlight and fire. In addition, do not expose it to rain, moisture and any kinds of liquid. This speaker is in compliance with the specified Bluetooth version. It does not guarantee compatibility of all functions on every Bluetooth enabled device. Please check with your mobile phone's user manual for compatibility and functionality. Please read these safety warnings and cautions carefully to ensure your personal safety and prevent property damage. Fire and Electric Shock Hazard Do not expose your PH-M90 to liquid, moisture, humidity, or rain. Do not use the PH-M90 near a bathtub, sink, sauna, pool, or steam room. Exposure of the PH-M90 to moisture could result in electric shock. Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects in to the PH-M90. Such actions could result in electric shock. Clean the PH-M90 only with a dry cloth. Do not expose your PH-M90 to extremely high or low temperatures. Do not leave your PH-M90 in direct sunlight for extended periods of time. Do not leave your PH-M90 near open flames such as cooking burners, candles, or fireplaces. Do not block any ventilation openings. Battery/Charger Hazard Do not dispose of your PH-M90 in a fire. The battery could explode causing injury or death. Only charge the battery in accordance with the user instructions supplied with the PH-M90. Do not attempt to disassemble the PH-M90 charger or force open the built-in battery because this may result in electric shock. Do not charge the PH-M90 in damp areas or in extremely high or low temperatures because this could result in electric shock. Do not clean the PH-M90 when it is being charged. Always unplug the charger first before cleaning the PH-M90. Automobile Accident Hazard Do not leave or store the PH-M90 or any of its accessories near or over your automobile's air bag because serious injury may result when an air bag deploys. Do not place the PH-M90 on high surfaces such as shelves. During music playback the PH-M90 may move which could cause the PH-M90 to shift and fall off of the edge. Documents / ResourcesHere you can download full pdf version of manual, it may contain additional safety instructions, warranty information, FCC rules, etc.Download Photive PH-M90 Rugged Bluetooth Speaker Manual